7544 Group

Timer A Operation (Pulse Width HL Continuously Measurement Mode)

1. Abstract

The following article introduces and shows an application example of pulse width HL continuously measurement mode of timer A.

2. Introduction

The explanation of this issue is applied to the following condition:
Applicable MCU: 7544 Group

3. Contents

Outline: An input signal is detected by using the pulse width HL continuously measurement mode.

Specifications: Whether a normal-range signal is input or not is judged by measuring a pulse width input from the $P0_0$/$CNTR_1$ pin.
$f(X_{IN})/16$ ($f(X_{IN})$ = 6.4 MHz) is used as the count source, and "H" and "L" pulse width of the input pulse are measured by using the pulse width HL continuously measurement mode. When the following conditions are satisfied, it is recognized as a normal value. When the following conditions are not satisfied, it is recognized as an unusual value.
200 ms ≤ "H" pulse width < 1.2 s
600 ms ≤ "L" pulse width of < 2.2 s
1.0 s ≤ one period ("H" pulse width + "L" pulse width) < 3.0 s
Operation clock: $f(X_{IN})$ = 6.4 MHz, high-speed mode

3.1 Example of Peripheral Circuit

Figure 1 shows an example of a peripheral circuit.



Figure 1 Example of peripheral circuit

3.2 Operation Timing When Pulse is Input

Figure 2 shows an operation timing when a pulse is input.



Figure 2 Operation timing when pulse is input

3.3 Example of Control Procedure

Figure 3 and Figure 4 show an example of control procedure.



Figure 3 Example of control procedure (1)



Figure 4 Example of control procedure (2)

4. Sample Programming Code

[Reset Start ••• Main Routine Process]

```
RESET:
          SEI                       ; Interrupt disable
          CLD
          CLT
;
          LDX  #$FF                 ; Set stack bottom
          TXS
;
          LDM  #%10000000,CPUM      ; Set CPU mode register
;
; Wait f(XIN) oscillation stabilizing time
;
          LDM  #%00000000,CPUM      ; Set CPU mode register
;
          LDA  #0
          LDX  #>RAM_top
RAM_clear:    STA  $00,X
          INX
          BNE  RAM_clear
;
          CLB  2,ICON2              ; TimerA interrupt disable
          CLB  6,ICON1              ; CNTR1 interrupt disable
;
          LDM  #%00000000,P0D       ; Set Port P0 direction register
;
          CLB  0,PULL               ; Port P00 Pull_up off
;
          LDM  #%10110000,TAM       ; Set Timer A mode register
;
          LDM  #%00000000,TCSS2     ; Set Timer count source set register 2
;
          LDM  #$1F,TAL             ; Set Timer A (low-order)
          LDM  #$4E,TAH             ; Set Timer A (high-order)
;
          SEB  7,INTEDGE            ; disable key on wake-up interrupt
;
          CLB  2,IREQ2              ; TimerA interrupt request clear
          CLB  6,IREQ1              ; CNTR1 interrupt request clear
          SEB  2,ICON2              ; TimerA interrupt enable
          SEB  6,ICON1              ; CNTR1 interrupt enable
;
          SEB  f_first_edge         ; ignore first edge

          CLB  7,TAM                ; start timer A count
;
          CLI
;
__MAIN:

          BBC  f_RING,__MAIN
               ;
               ;  process
               ;
          BRA  __MAIN
;
```

5. Reference

Data Sheet
7544 Group Data sheet
7544 Group Data sheet (QzROM Version)

Before using this manual, please visit our website to verify that this is the most updated document available.

Renesas Technology Corporation Semiconductor Home Page
http://www.renesas.com/en/740

E-mail Support
E-mail: support_apl@renesas.com

REVISION HISTORY	7544 Group Timer A Operation (Pulse Width HL Continuously Measurement Mode)

Rev.	Date	Description	
		Page	Summary
1.00	Apr 01, 2003	-	First Edition issued
2.00	Nov 12, 2004	2-4	Contents: Specifications and Figures 1 to 3 revised.
		5	Sample Programming Code added.

Keep safety first in your circuit designs!

1. Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage.
   Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation or a third party.
2. Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein.
   The information described here may contain technical inaccuracies or typographical errors.
   Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.
   Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (http://www.renesas.com).
4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
5. Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
6. The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.
   Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
8. Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.